



KOVIX KGA Ground Anchor Installation

1. Position ground anchor in desire location and unlock and remove the top plate.
2. Use a 16mm drill bit to mark the two holes in the base plate.
3. Remove the base plate and drill the two holes to a depth of 85mm.
4. Remove any debris from the holes and surrounding area.
5. Place the base plate in location marrying up the holes in the base plate with the floor.
6. Knock the provided expansion bolts through the base plate and into the holes.
7. Using the Allen Key provided fully tighten the expansion bolts up.
8. Insert your chain into the outer shell and lock the top plate into place.
9. The installation is now competed.

